
# **ALDER LED MIRROR**


LMMB2, LMBN2, LMPC2, LMBB2






### **INCLUDED HARDWARE**

Wall Anchors, Screws Wall Mount Bracket



### **TOOLS YOU MAY NEED:**

Phillips head screwdriver, Hammer Pencil, Level, Tape Measure, Drill



### STEP 1:

- ·Locate hanging hardware before discarding any packaging.
- Determine installation location. For best results, always install mirror into one or more wall studs. When a stud is not available, use wall anchors.

- •Measure, level and center the mounting bracket in desired location on the wall in direction shown.
- Mark the anchor and/or screw placement using a pencil through the wall mount bracket.






### **STEP 3:**


### **SOLID WOOD OR STUD MOUNT:**

• Fasten screws through wall mount bracket.



### **DRYWALL MOUNT:**

- Drill pilot holes and insert plastic anchors into drilled holes using hammer to tap the anchors flush with the wall. Be careful when hammering not to damage the anchor or surrounding wall.
- Position wall mount bracket over installed anchors.
- Fasten screws through wall mount bracket into anchors.
- •Make sure to follow these steps for all holes in wall mount bracket for secure installation.




## STEP 4:

•Connect the electrical power cord to a properly grounded outlet. Connect only to a circuit protected by a Class A Ground-Fault Circuit-Interrupter (GFCI) which protects against line-to-ground shock hazard.

WARNING: Improper installation will create an electrical hazard if it does not comply with local building and electrical codes.



www.luca-lex.com • 978-296-5578



www.luca-lex.com • 978-296-5578